



**1.** Den anbefalede afstand mellem magneternes center er 28 cm.

Brug målebånd og vaterpas.

The recommended distance between the magnets is 28 cm.

Use tape measure and level.

**2.** Bor huller til rawlplugs. 10 mm.

Drill holes for the wall plugs. 10 mm.



**3.** Montér gips / beton rawlplugs og skru gevindstang i.

Mount plaster / concrete wall plugs and screw in the threaded rod.

**4.** Skru magnet på.

Attach the magnets.