



1. Den anbefalede afstand mellem magneternes center er 25 cm.

Brug målebånd og vaterpas.

The recommended distance between the magnets is 25 cm.

Use tape measure and level.

2. Bor huller til rawlplugs. 6 mm.

Drill holes for the wall plugs. 6 mm.



3. Montér gips / beton rawlplugs.

Mount plaster / concrete wall plugs.

4. Skru magnetter på.

Attach the magnets.

5. Træbrikkerne er ubehandledes. Oliebehandling gør dem mørkere.

Sæbespåner bibeholder den alm. struktur.

The wooden pieces are untreated. Oil treatment will make the pieces darker.

Soap flake treatment will maintain the original structure.

6. Plexiglasset pudses med glasklud. Brug aldrig et spritholdigt produkt, men blot lunkent vand.

Polish the Plexiglas with a microfiber glass cloth. Use lukewarm water instead of alcohol